

Hinweise zum Gebrauch

DEUTSCH

Liebe Kundin, lieber Kunde,
wir freuen uns, dass Du dich für die **Easy Exit Card by CAIRON** entschieden hast. Damit hast Du ein kompaktes, effektives Rettungswerkzeug immer griffbereit.

Solltest Du Fragen zum Produkt oder zur Anwendung haben, kontaktiere den Kundenservice über:

kundenservice@easyexitcard.com

Bestimmungsgemäßer Gebrauch

- Das Produkt ist als Rettungswerkzeug für Notfälle konzipiert und dient zum Zerschlagen von **einschichtigen** Fahrzeugscheiben oder Fahrzeugsicherheitsglas („tempered glass“ / „vorgespanntes Glas“) sowie zum Durchschneiden von Sicherheitsgurten.
- Das Produkt eignet sich **nicht** zum Zertrümmern von Windschutzscheiben, Heckscheiben, Mehrschichtglas, Verbundglas, laminiertem Glas, Panzerglas oder Scheiben aus Kunststoff.
- Das Produkt ist für den privaten Gebrauch, nicht für eine gewerbliche Nutzung bestimmt.
- Nur für den angegebenen Zweck und nur wie in den Hinweisen zum Gebrauch beschrieben nutzen. Jede darüber hinausgehende Verwendung gilt als bestimmungswidrig.
- Von der Gewährleistung ausgeschlossen sind alle Mängel, die durch unsachgemäße Behandlung, Beschädigung oder Reparaturversuche entstehen. **Dies gilt auch** für den normalen Verschleiß.

Sicherheitshinweise

- Das Produkt ist **kein** Spielzeug! Kinder und Tiere mit dem Produkt nicht unbeaufsichtigt lassen. Es besteht Verletzungsgefahr durch falsche Benutzung.
- Vorsicht im Umgang mit Karte und Schutzhülle. Es besteht Verletzungsgefahr durch den spitzen Dorn sowie die scharfe Klinge.
- Das Produkt schützen vor Feuer, extremen Temperaturen, lang anhaltender, direkter Sonneneinstrahlung sowie Flüssigkeiten jeglicher Art, insbesondere Lösungsmittel etc.
- Das Produkt regelmäßig überprüfen. Nur verwenden, wenn es unbeschädigt ist.

Lieferumfang

1 x Karte inkl. Dorn
1 x Schutzhülle inkl. Gurtschneider
1 x Schutzkappe
1 x Hinweise zum Gebrauch
1 x Befestigungsklammer (optional erhältlich)

Auf Vollständigkeit und Transportschäden überprüfen. Bei Schäden nicht verwenden, sondern den Kundenservice kontaktieren.

Scheibe zerschlagen



Seitenscheiben lassen sich aufgrund ihres Aufbaus am besten zerschlagen, sofern sie die im Kapitel „Bestimmungsgemäßer Gebrauch“ genannten Kriterien erfüllen.

Die Karte kann **sowohl innen als auch außen** an der Fahrzeugscheibe angewandt werden.

1. Karte mit der abgeflachten Kante **bis zur roten Markierung** zwischen Fahrzeugscheibe und Scheibendichtung schieben (**Bild A**). **Der Dorn muss zur Scheibe zeigen.**
2. Das andere Ende der Karte im 45°-Winkel wegziehen (**Bild B**).
3. Das **Gesicht** von der Scheibe abwenden, um Verletzungen durch umherfliegende Glassplitter zu vermeiden.
4. Die Karte loslassen. Sobald der Dorn mit Schwung auf die Scheibe trifft, wird diese zerschlagen (**Bild C**).

Gurt durchschneiden

1. Die Schutzkappe von der Schutzhülle abziehen.
2. Den Sicherheitsgurt strammziehen. Gleichzeitig die Schutzhülle mit der integrierten Klinge am Sicherheitsgurt ansetzen und diesen möglichst diagonal durchschneiden (**Bild D**).

Aufbewahrung

Beachten!

- Die Karte zur Aufbewahrung **nicht dauerhaft** an die Scheibe stecken.
- Bei Nichtgebrauch die Karte in der Schutzhülle verstauen und die Schutzkappe aufstecken.
- Vor direkter Sonneneinstrahlung geschützt sowie außerhalb der Reichweite von Kindern und Tieren aufbewahren.
- Um Karte und Hülle mit Gurtschneider sicher und erreichbar zu platzieren, kann die optional erhältliche Befestigungsklammer verwendet werden.

Austausch

- **Die Karte nach einmaligem Gebrauch ersetzen.**
- Ansonsten sollte das Produkt ersetzt werden, sobald es sichtbare Beschädigungen, Brüche oder Anzeichen von Materialermüdung aufweist.

Die volle Funktionalität des Produkts kann in diesen Fällen nicht mehr garantiert werden.





Entsorgung



Das Verpackungsmaterial umweltgerecht entsorgen und der Wertstoffsammlung zuführen. Auch das Produkt umweltgerecht entsorgen.

Die Abfallvermeidung leistet einen noch wertvolleren Beitrag zum Umweltschutz. Sofern möglich, ist daher neben einer weiteren eigenen Nutzung auch die Abgabe an Zweitnutzer eine ökologisch wertvolle Alternative zur Entsorgung.

Alle Rechte vorbehalten.



Hergestellt für:

CAIRON Group GmbH

Kilianstraße 137, 33098 Paderborn

www.easyexitcard.com

Kundenservice:

kundenservice@easyexitcard.com

ID: Cairon 01/26V1

Easy Exit Card

by  CAIRON

Instructions for Use

ENGLISH

Dear Customer,

We are delighted that you have chosen the **Easy Exit Card by CAIRON**. This gives you a compact, effective rescue tool at your fingertips.

If you have any questions about the product or its use, please contact the customer service department via:

kundenservice@easyexitcard.com

Intended Use

- This product is designed as an emergency rescue tool for breaking **single-layer** vehicle windows or vehicle safety glass ("tempered glass") and cutting seat belts.
- The product is **not** suitable for breaking windshields, rear windows, multi-layer or laminated glass, bullet-proof glass or plastic windows.
- The product is intended for private use, not for commercial use.
- Use only for the specified purpose and only as described in the instructions for use. Any use beyond this is deemed to be improper.
- The warranty does not cover faults caused by incorrect handling, damage or attempted repairs. The same applies to normal wear and tear.

Safety Notices

- The product is **not** a toy! Do not leave children and animals unsupervised with the product. There is a danger of injury from incorrect use.
- Be careful when handling the card and protective cover. There is a risk of injury from the sharp spike and blade.

- Protect the product from fire, extreme temperatures, persistent direct sunlight and liquids of any kind, especially solvents, etc.
- Check the product regularly. Use only if it is undamaged.

Items Supplied

- 1 x Card including spike
- 1 x Protective cover including seat belt cutter
- 1 x Protective cap
- 1 x Instructions for use
- 1 x mounting clip (optionally available)

Check the items supplied for completeness and transport damage. If you find any damage, do not use the product but contact our customer service department.

Breaking a Vehicle Window



Side windows are easiest to break due to their structure, provided they meet the criteria listed in the "Intended Use" chapter.

The card can be used on **both the inside and outside** of the vehicle window.

1. Slide the card with the flattened edge **up to the red mark** between the vehicle window and the window seal (**Picture A**). **The spike must point towards the window.**
2. Pull the other end of the card away at a 45° angle. (**Picture B**).
3. Turn your **face** away from the window to avoid injury from flying glass fragments.
4. Release the card. As soon as the spike hits the window with force, it is shattered (**Picture C**).

Cutting a Seat Belt

1. Remove the protective cap from the protective cover.
2. Tighten the seat belt. At the same time, place the protective cover with the integrated blade on the seat belt and cut it diagonally if possible (**Picture D**).

Storage

Please note!

- **Do not** permanently attach the card to the window for storage.
- When not in use, store the card in the protective cover and place the protective cap on it.
- Store away from direct sunlight and out of reach of children and animals.
- An optional mounting clip can be used to securely fix the card and sleeve with the belt cutter in the vehicle, keeping them within easy reach.

Replacement

Replace the card after one use.

- Otherwise, the product should be replaced as soon as it shows visible damage, breakage, or signs of material fatigue.

In these cases, the full functionality of the product can no longer be guaranteed.





Disposal



Dispose of the packaging material in an environmentally friendly manner so that it can be recycled. Dispose of the product in an environmentally friendly manner as well.

Waste prevention makes an even more valuable contribution to protecting the environment. This means if possible, as well as continuing to use, passing it on to another user also represents an ecologically beneficial alternative to disposal.

All rights reserved.



Manufactured for:

CAIRON Group GmbH

Kilianstraße 137, 33098 Paderborn

www.easyexitcard.com

Customer Service:

* kundenservice@easyexitcard.com

ID: Cairon 01/26V1